SECTION IDX

ALPHABETICAL INDEX

A

A/C air flow ATC-30, MTC-26
A/C component layout ATC-21, MTC-21
A/C compressor clutch removal and installation ATC-123, MTC-82
A/C compressor mounting ATC-121, MTC-80
A/C compressor precaution ATC-9, MTC-9
A/C compressor special service tool . ATC-12, MTC-12
A/C control operation (manual A/C) MTC-25
A/C controller ATC-98, MTC-61
A/C diagnostic work flow (auto A/C) ATC-42
A/C HFC134a (R134a) system precaution ATC-4, MTC-4
A/C HFC134a (R134a) system service procedure ATC-119, MTC-9, MTC-78
A/C HFC134a (R134a) system service tools .. ATC-13, MTC-13
A/C HFC134a system service equipment precaution ... ATC-9, MTC-9
A/C lubricant (R134a) ATC-5, ATC-22, ATC-136, MTC-22, MTC-94
A/C operational check ATC-50, MTC-36
A/C self-diagnoses (auto A/C) ATC-87
A/C service data specification ATC-136, MTC-94
A/C symptom chart (auto A/C) ATC-32, MTC-28
A/C system description (auto A/C) ATC-25
A/C trouble diagnoses (auto A/C) ATC-32, MTC-28
A/C, A - Wiring diagram ATC-36
A/C, M - Wiring diagram MTC-32
A/T fluid checking AT-16, MA-20
A/T fluid replacement AT-17, MA-21
A/T fluid temperature sensor AT-105
A/T IND - Wiring diagram DI-38
A/T shift control system AT-242
A/T shift lock system AT-245
A/T shift lock system - Wiring diagram AT-246
A/T trouble diagnoses AT-42
A/T Wiring diagram AT - 1ST AT-118
A/T Wiring diagram AT - 2ND AT-123
A/T Wiring diagram AT - 3RD AT-128
A/T Wiring diagram AT - 4TH AT-133
A/T Wiring diagram AT - CAN AT-94
A/T Wiring diagram AT - ENG SS AT-113
A/T Wiring diagram AT - FTS AT-102
A/T Wiring diagram AT - LPSV AT-152
A/T Wiring diagram AT - MAIN AT-188
A/T Wiring diagram AT - OVRCSV AT-173
A/T Wiring diagram AT - PNP/SW AT-97
A/T Wiring diagram AT - SSV/A AT-158
A/T Wiring diagram AT - SSV/B AT-163
A/T Wiring diagram AT - TCCSIG AT-145
A/T Wiring diagram AT - TCV AT-139
A/T Wiring diagram AT - TPS AT-169
A/T Wiring diagram AT - VSS A/T AT-108
A/T Wiring diagram AT - VSSMTR AT-178
Accelerator control system ACC-3
Accelerator pedal position (APP) sensor EC-553, EC-560, EC-576
Accelerator pedal released position learning EC-77
Air bag SRS-2
Air bleeding (hydraulic clutch) CL-7
Air cleaner and air duct EM-14
Air cleaner filter EM-14
Air cleaner filter replacement MA-14
Air conditioner - Wiring diagram ATC-35, MTC-31
Air conditioner cut control EC-26
Air flow meter - See Mass air flow sensor EC-178, EC-187
Air mix door control linkage adjustment MTC-38, MTC-72
Air mix. door motor ATC-59, ATC-113
Air spoiler, rear EI-30
Alternator SC-20
Ambient sensor ATC-88, ATC-99
Angular tightening application EM-3
Antenna - See Power antenna AV-15
APPS1 - Wiring diagram EC-555
APPS2 - Wiring diagram EC-562
APPS3 - Wiring diagram EC-578
ASC/BS - Wiring diagram EC-508
ASC/SW - Wiring diagram EC-500
ASCBOF - Wiring diagram EC-585
ASCD EC-27
ASCD (automatic speed control device) ACS-2
ASCD brake switch EC-506, EC-584
ASCD indicator lamp EC-594
ASCD steering switch EC-498
ASCIND - Wiring diagram EC-595
Audio AV-5
Auto air conditioner - Wiring diagram ATC-36
Auto amp ATC-40, ATC-51, ATC-98
Automatic amplifier ATC-51
Automatic transmission fluid replacement MA-20, MA-22
AWD - Wiring diagram TF-17
AWD control unit inspection table TF-21
Axle MA-27

B

Back door BL-71
Back door window GW-15
Back window GW-15
BACK/L - Wiring diagram LT-35
Back-up lamp LT-35
Back-up lamp switch (M/T) MT-13
Basic inspection EC-70
Battery/Starting/Charging System Tester SC-7, SC-12, SC-22
Baulk ring (M/T) MT-20
Block heater EM-82
Blower motor ATC-65, ATC-105, MTC-42, MTC-45, MTC-64
Blower resistor MTC-66
Blower unit ATC-103, MTC-62
Boring/horning cylinder block EM-103
Brake fluid level MA-25

Brake inspection MA-25
Brake lines and cables inspection MA-25
Brake pedal BR-6
Brake switch EC-526
BRK/SW - Wiring diagram EC-527
Bulb specifications LT-74
Bumper, front EI-14
Bumper, rear EI-16

C

Camshaft EM-37
Camshaft inspection EM-40
Camshaft position sensor (PHASE) EC-335
CAN DI-55
CAN - Wiring diagram EC-153, LAN-18, LAN-27, LAN-34, LAN-41, LAN-50, LAN-58
CAN communication ... EC-29, EC-152, AT-31, AT-93, TF-13, TF-36
CHARGE - Wiring diagram SC-21
Charging system SC-20
Chassis and body maintenance MA-19
CHIME - Wiring diagram DI-44
Circuit breaker PG-12
Closed loop control EC-23, EC-477
Clutch cover CL-14
Clutch disc CL-14
Clutch master cylinder CL-8
Clutch operating cylinder CL-10
Clutch pedal CL-5
Clutch release bearing CL-12
Clutch release mechanism CL-12
Clutch withdrawal lever CL-12
Coil spring (rear) RSU-10
Collision diagnosis SRS-39
Combination meter DI-4
Combination switch LT-31
Component Location (auto A/C) ATC-33, MTC-29
Compression pressure EM-62
Compressor clutch removal and installation . ATC-123, MTC-82
Compressor mounting ATC-121, MTC-80
Compressor precaution ATC-9
Compressor special service tool ATC-12, MTC-12
Condenser ATC-128, MTC-87
Connecting rod EM-101
Connecting rod bearing clearance EM-105
Connecting rod bushing clearance EM-101
CONSULT-II for engine EC-112
Control lever (M/T) MT-14
Control unit ATC-98, MTC-61
Control units (terminal arrangement) PG-48
Converter housing installation AT-369
COOL/F - Wiring diagram EC-484
Coolant replacement MA-12
Cooling circuit (engine) CO-6
Cooling fan CO-18
Cooling fan motor EC-492
Cooling fan relay EC-492
Coupling sleeve (M/T) MT-20
Cowl top EI-19
Cowl top cover EI-19
Crankshaft EM-83
Crankshaft position sensor (POS) EC-327
Cylinder block EM-82
Cylinder block boring EM-104
Cylinder head EM-62
Cylinder head bolt tightening EM-65

D

Data link connector EC-657
Desiccant Assembly ATC-29, ATC-129, MTC-25, MTC-88
Diagnosis sensor unit SRS-38
Diagnostic trouble code (DTC) for OBD system . EC-8, EC-51
Diagnostic trouble code (DTC) inspection priority chart EC-89
Differential gear (FF M/T) MT-23
Door glass GW-56, GW-59
Door glass Fitting Adjustment GW-56, GW-59
Door lock BL-65, BL-68
Door trim EI-32
Door, front BL-19
Door, rear BL-19
Drive belt EM-11
Drive shaft MA-27
Drive shaft (front) FAX-13
Drive shaft (rear) RAX-21
Driver air bag SRS-30
Dropping resistor (A/T) AT-156
DTC work support EC-123
Duct and grilles ATC-115, MTC-74

E

ECM input/output signal EC-104
ECM power supply EC-144, EC-447
ECM relay EC-151
ECM/PW - Wiring diagram EC-448
ECTS - Wiring diagram EC-203
Electric sunroof RF-10
Electric throttle control actuator EC-538, EC-546, EC-551
Electrical load signal circuit EC-598
Electrical unit PG-48
Electrical units location PG-43
Electronic ignition (EI) system EC-24
Engine control circuit diagram EC-102
Engine control component parts location EC-96
Engine control module (ECM) EC-451
Engine control system diagram and chart EC-21
Engine coolant CO-8
Engine coolant temperature sensor (ECTS) ... EC-201, EC-215
Engine fail-safe system EC-91
Engine oil LU-6

Engine oil filter replacement MA-16
Engine oil precautions GI-7
Engine removal EM-74
ETC1 - Wiring diagram EC-539
ETC2 - Wiring diagram EC-533
ETC3 - Wiring diagram EC-547
EVAP canister EC-33
EVAP canister purge volume control solenoid valve EC-364, EC-372
EVAP canister vent control valve EC-379, EC-386
EVAP control system (small leak) diagnosis .. EC-354, EC-411, EC-419
EVAP control system pressure sensor EC-393, EC-396, EC-403
EVAP control system purge flow monitoring diagnosis EC-348
EVAP vapor lines inspection MA-18
Evaporative emission (EVAP) system EC-30
Evaporator ATC-130, MTC-89
Exhaust manifold EM-20
Exhaust system EX-2
Exhaust system inspection EX-2, MA-19
Expansion valve ATC-131, MTC-90
Exterior EI-20, EI-21, EI-23, EI-24, EI-25, EI-28, EI-30, EI-31

F

F/FOG - Wiring diagram LT-44
F/PUMP - Wiring diagram EC-618
Fan control amp. ATC-107
Fan switch ATC-29, MTC-45
Final drive (FF M/T) MT-23
Finisher, interior - See Trim EI-32
Finisher, rear panel EI-31
Floor trim EI-39
Flow charts GI-26
Fluid temperature sensor (A/T) AT-105
Fluorescent leak detector ATC-132, MTC-91
Flywheel (clutch) CL-14
Flywheel runout EM-108
Fog lamp, front LT-43
Fork rod (M/T) MT-22
Freeze frame data EC-52
Front bumper EI-14
Front door BL-19
Front Door Trim EI-32
Front fog lamp LT-43
Front passenger air bag SRS-35
Front seat SE-17
Front seat belt SB-3
Front seat belt pre-tensioner SB-2, SRS-2, SRS-37
Front suspension FSU-6
FTTS - Wiring diagram EC-298, EC-303
FUEL - Wiring diagram EC-283, EC-291
Fuel cut control (at no load high engine speed) . EC-25
Fuel filler lid BL-75
Fuel filter replacement FL-4
Fuel gauge DI-4
Fuel injection system EC-281, EC-289
Fuel injector and fuel tube EM-30
Fuel level sensor EC-430, EC-432, EC-434
Fuel line inspection FL-3, MA-14
Fuel precautions GI-5
Fuel pressure check EC-80
Fuel pressure release EC-80
Fuel pump EC-617
Fuel pump and gauge FL-4
Fuel pump relay EC-622
Fuel system FL-3
Fuel tank FL-11
Fuel tank temperature sensor EC-296, EC-302
Fuel tank vacuum relief valve EC-33
Fuse PG-12
Fuse and fusible link box PG-52
Fusible link PG-12

G

Gauges DI-4
Gear components (M/T) MT-20
Generator SC-20
Generator - See Alternator SC-20
Generic scan tool (GST) EC-125
Glass GW-56, GW-59
Grille - See Exterior EI-18
Ground distribution PG-13

H

H/LAMP - Wiring diagram LT-9
Harness connector PG-46
Harness layout PG-23
Headlamp LT-5
Headlining - See Roof trim EI-40
Heated oxygen sensor 1 .... EC-223, EC-231, EC-242, EC-465, EC-471
Heated oxygen sensor 1 heater EC-159
Heated oxygen sensor 2 ..... EC-251, EC-260, EC-272
Heated oxygen sensor 2 heater EC-166
Heater and cooling unit (Heater core) ATC-109, MTC-68
Heater unit (heater core) ATC-114, MTC-73
HFC134a (R134a) system precaution . ATC-4, MTC-4
HFC134a (R134a) system service procedure ATC-119, MTC-9, MTC-78
HFC134a (R134a) system service tools ATC-13, MTC-13
HFC134a system service equipment precaution ATC-9, MTC-9
HO2S1 - Wiring diaram EC-225, EC-234, EC-245
HO2S1H - Wiring diagram EC-161
HO2S2 - Wiring diagram EC-254, EC-263, EC-275
HO2S2H - Wiring diagram EC-168
Hood BL-12
Horn WW-18
HORN - Wiring diagram WW-18
How to erase DTC for OBD system EC-60

I

IATS - Wiring diagram EC-197
Identification ATC-10, ATC-11, MTC-10, MTC-11
Idle air volume learning EC-78
Idle speed EC-70
Idle speed control (ISC) EC-438, EC-440
Ignition coil EM-27, EC-632
Ignition control system EC-623
Ignition timing EC-70
IGNSYS - Wiring diagram EC-624
In vehicle sensor ATC-90, ATC-100
In-cabin Microfilter ATC-108, MTC-67
INJECT - Wiring diagram EC-612
Injector EC-611
Input shaft (FF M/T) MT-20
Intake air temperature sensor EC-195, EC-218
Intake door motor ATC-62, ATC-106, MTC-39, MTC-65
Intake manifold EM-16
Intake manifold collector EM-16
Intake sensor ATC-96, ATC-102
Intake valve timing control EC-155
Intake valve timing control solenoid valve EC-173
Interior EI-32, EI-35, EI-36, EI-39, EI-40
IVC - Wiring diagram EC-174
IVIS (Infiniti vehicle immobilizer system) precautions ... GI-3

J

Joint connector (J/C) PG-51

K

Keyless entry system - See Multi-remote control system BL-45
Knock sensor (KS) EC-322
KS - Wiring diagram EC-323

L

LAN system circuit ATC-25, ATC-53
License lamp LT-37
Line pressure test (A/T) AT-54
Liquid gasket application EM-4, LU-2, CO-2
LOAD - Wiring diagram EC-599, EC-605, EC-608
Location of electrical units PG-43
Lock, door BL-65, BL-68
Lubricant (R134a) A/C ATC-5, ATC-22, ATC-136, MTC-5, MTC-22, MTC-94
Lubrication circuit (engine) LU-4

M

M/T major overhaul MT-19
M/T oil replacement MT-11
M/T removal and installation MT-17
MAFS - Wiring diagram EC-181, EC-189
Magnet clutch ... ATC-71, ATC-123, MTC-46, MTC-82
MAIN - Wiring diagram EC-144
Mainshaft (M/T) MT-20
Maintenance (engine) MA-12
Major overhaul (Transfer) TF-50
Malfunction indicator lamp (MIL) EC-61
Mass air flow sensor (MAFS) EC-178, EC-187
Master cylinder (clutch) CL-8
Meter DI-4
METER - Wiring diagram DI-10
MI/DL - Wiring diagram EC-657
MIRROR - Wiring diagram GW-63
Misfire EC-315
Mode door control linkage adjustment ATC-112, MTC-37, MTC-71
Mode door motor ATC-56, ATC-112
Molding - See Exterior EI-21, EI-23, EI-24
Mud guard - See Exterior EI-23
MULTI - Wiring diagram BL-49
Multiport fuel injection (MFI) system EC-22
Multiport fuel injection precautions GI-6
Multi-remote control system BL-45

N

NATS - Wiring diagram BL-100
NVH troubleshooting (EM) EM-9
NVH troubleshooting (ST) PS-6
NVH troubleshooting (Transfer) TF-8
NVIS (Nissan vehicle immobilizer system) precautions GI-3

O

Oil cooler (engine) LU-10
Oil filter LU-9
Oil pan (engine) EM-22
Oil pressure (engine) LU-6
Oil pump (engine) LU-12
Oil pump regulator valve (engine) LU-12
Oil seal replacement (engine) . EM-49, EM-59, EM-62, EM-82
Oil seal replacement (front of final drive) RFD-9
On board diagnostic system EC-47
Operating cylinder (clutch) CL-10
ORVR (On-board Refueling Vapor Recovery) ... EC-37
Overdrive control switch AT-240
Overheat EC-480
Oversize piston EM-104

P

Park/Neutral position switch EC-460
Park/neutral position switch (A/T) AT-96
Park/neutral position switch (M/T) MT-13
Parking brake control PB-3
PCV (positive crankcase ventilation) EC-44
PGC/V - Wiring diagram EC-366, EC-374
PHASE - Wiring diagram EC-337
Pilot bushing replacement - See Pilot converter EM-82

Piston assembly EM-103
Piston pin inspection EM-99
Piston ring inspection EM-100
Piston to bore clearance EM-103
PNP/SW - Wiring diagram EC-462
POS - Wiring diagram EC-329
POWER - Wiring diagram PG-3
Power antenna AV-15
Power door lock BL-23
Power seat SE-10
Power socket WW-20
Power steering fluid level PS-7, MA-26
Power steering gear PS-17
Power steering oil pump PS-28
Power steering pressure (PSP) sensor EC-442
Power supply routing PG-2
Power window GW-33
PRE/SE - Wiring diagram EC-398, EC-405
Precations for Leak detection dye ATC-10, MTC-10
Precautions (General) GI-4
Pressure plate - See Clutch cover CL-14
Propeller shaft PR-3
Propeller shaft on vehicle service PR-3
PS/SEN - Wiring diagram EC-443

R

Radiator CO-11, CO-14
Radio - See Audio AV-5
Rear air spoiler EI-30
Rear bumper EI-16
Rear disc brake BR-31
Rear door BL-19
Rear panel finisher EI-31
Rear seat SE-24
Rear seat belt SB-4
Rear side window GW-13
Rear suspension RSU-5
Rear washer WW-12
Rear window defogger GW-17
Rear wiper WW-12
Refrigerant connection precaution ATC-6, MTC-6
Refrigerant discharging evacuating charging ATC-119, MTC-78
Refrigerant general precaution ATC-5, MTC-5
Refrigerant lines ATC-119, MTC-78
Refrigerant pressure sensor EC-634, ATC-130, MTC-89
Refrigeration cycle ATC-16, MTC-16
Release bearing (clutch) CL-12
Removal and installation (Transfer) TF-48
Reverse idler shaft (M/T) MT-20
Reverse lamp switch (M/T) - See Back-up lamp switch (M/T) MT-13
Reverse main gear (M/T) MT-20
Road test AT-56, AT-59, AT-62, AT-63
Rocker cover EM-35
RP/SEN - Wiring diagram EC-635

S

S/LOCK - Wiring diagram BL-27
SAE J1979 - Service $01 - 09 ..... EC-47
SEAT - Wiring diagram SE-10
Seat belt inspection SB-6
Seat belt, front SB-3
Seat belt, rear SB-4
Seat, front SE-17
Seat, rear SE-24
Self-diagnosis (Transfer) TF-23
SEN/PW - Wiring diagram EC-455
SHIFT - Wiring diagram AT-246
Shift control components (M/T) MT-22
Shift fork (M/T) MT-22
Shift lever MT-14
Shift lock system AT-245
Shift schedule AT-376
Side air bag (satellite) sensor SRS-36
Side window - See Rear side window GW-13
Smart entrance control unit BCS-3
SNOW MODE SW EC-640
Spark plug EM-28
Spark plug replacement MA-17
Specification value EC-133
Speedometer DI-4
Spiral cable SRS-33
SROOF - Wiring diagram RF-11
SRS - See Supplemental Restraint System SRS-4
SRS Trouble diagnoses SRS-6
Stall test (A/T) AT-51
Standardized relay PG-49
Steering gear and linkage inspection MA-26
Steering knuckle FAX-7
Steering linkage PS-17
Steering wheel and column PS-9, PS-12
Stop lamp LT-33, LT-47
Stop lamp switch EC-526
STOP/L - Wiring diagram LT-33
Strut (rear) RSU-10
Sunload sensor ATC-93, ATC-101
Sunroof RF-10
Supplemental Restraint System SRS-4
Suspension MA-27
Symbols and abbreviations GI-9, GI-22
Symptom matrix chart EC-92
Synchronizer (M/T) MT-20
System readiness test (SRT) code EC-52

T

Tachometer DI-4
Tail lamp LT-37
TAIL/L - Wiring diagram LT-37, LT-64
TCM inspection table AT-76
THEFT - Wiring diagram BL-81
Thermostat CO-22
Three way catalyst EM-20
Three way catalyst function EC-343

Three way catalyst precautions GI-5
Throttle body EM-19
Throttle control motor relay EC-531
Throttle position sensor (TPS) EC-207, EC-307, EC-494, EC-496, EC-568
Throwout bearing - See Clutch release bearing CL-12
Timing chain EM-49
Tire rotation MA-24
Top tether strap child restraint SB-9
Torque converter installation AT-261, AT-369
TPS1 - Wiring diagram EC-309
TPS2 - Wiring diagram EC-209
TPS3 - Wiring diagram EC-570
Transmission case (M/T) MT-19
Trouble diagnoses GI-10
TURN - Wiring diagram LT-26
Turn signal lamp LT-24
Two trip detection logic EC-47

V

Vacuum hose (brake system) BR-24
Vacuum hose drawing (Engine control) EC-101
Valve clearance EM-46
Valve guide EM-70
Valve lifter EM-37
Valve seat EM-72
Valve spring EM-73
Variable induction air control system (VIAS) .. EC-521, EC-647
VDC -Wiring diagram BRC-52
Vehicle speed sensor (VSS) EC-436, EC-517, EC-519
VENT/V - Wiring diagram EC-381, EC-388
Ventilation air filter ATC-108, MTC-67
VIAS - Wiring diagram EC-649
VIAS/V - Wiring diagram EC-522
VIN registration EC-77

W

Washer, rear WW-12
Water control valve CO-22
Water pump CO-20
Water temperature gauge DI-4
Weatherstrip - See Exterior BL-22
Wheel alignment (front) FSU-6
Wheel balance WT-5, MA-23
Wheel bearing (front axle) FAX-7
Wheel bearing (rear) RAX-5, RAX-15
Wheel hub (front) FAX-7
WINDOW - Wiring diagram GW-39
Window, back GW-15
Window, back door GW-15
Window, door GW-56, GW-59
Window, rear side GW-13
Window, side - See Rear side window GW-13
WIP/R - Wiring diagram WW-12
Wiper, rear WW-12
Wiring Diagram (Cell code) list PG-40
Wiring diagrams GI-14
Withdrawal lever (clutch) CL-12
Wrist pin - See Piston pin inspection EM-99